QUICK START GUIDE

Included with your RBR*coda*³ T.ODO

▶ Storage cap
▶ USB stick containing Ruskin software and documentation
▶ Cables
▶ Calibration certificates*

*Calibration certificates are available in Ruskin. To download, connect your instrument, go to **Information**, and select the **Download** button.

Deploy

RBR realtime sensors begin streaming data as soon as power is provided. The data streamed or fetched from your RBR*coda*³ T.ODO are automatically saved to your computer.

Protect your optode

The RBR optical dissolved oxygen sensors have an oxygen-sensitive substrate that requires special care. Any damage will permanently affect performance.

▶ Avoid direct sunlight
▶ Never touch the sensitive element while cleaning or handling
▶ Use the storage cap when the sensor is not in use

Deployment considerations

RBR ships the RBR*coda*³ T.ODO sensors with a hydrated storage cap on, so that the instrument is ready for its first deployment.

*Note: Long transportation times and low cabin pressure may result in the loss of water. Verify that the storage cap is still wet. If not, rehydrate the sensor for **five** days before deployment. See page 2 for details.*

Follow these precautions to ensure faultless operation:

▶ Do not exceed the maximum depth rating (6000m)
▶ Do not apply physical stress to the housing
▶ Do not attempt to open the sensor

For mooring or mounting applications, contact RBR for proper clamps and brackets. Improper mounting may damage the sensor.

Before any subsequent deployment, rehydrate the optode for at least **five** days.

Short-term storage (three weeks or less)

1. Fill the storage cap with distilled water until about 50% full.
2. Place the cap on the sensor and gently push it past the locking pin.

3. Refill the water once a week during storage.

Long-term storage (more than three weeks)

For longer storage periods, store your sensor dry.

1. Place an empty cap on the sensor and gently push down until it stops.
2. Before deployment, refill the cap with distilled water like for short-term storage and rehydrate for **five** days.

   Note: It takes up to five days for a dry optode to equilibrate after being placed in water. Insufficient hydrating time before deployment may lead to unreliable data.


Support

To access support within the Ruskin app, navigate to **Help** > **Comment on Ruskin...**. For technical support, please reach out to support@rbr-global.com, call

+1 613 599 8900 (UTC-5), or visit rbr-global.com/support/service.